



Model specific instructions

•	Triumph Bonneville Bobber
•	Triumph Bonneville Speedmaster (2018 and newer)

For:

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the BoosterPlug.com website:

http://www.boosterplug.com/shop/cms-downloads.html

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed.
- Remove the left hand side cover to access to the AIT sensor in the left hand side of the air filter box.
- See the pictures below to locate the AIT sensor in the air filter box.
- You have several choices for the BoosterPlug sensor location, but our favorite place on the Bobber is next to the airbox snorkel air intake hole. Or you could route the sensor rearward and down to a location near the rear wheel (Keep the sensor away from exhaust heat).
 - Just stick to the simple rules in the general installation instructions for placing the external sensor, and you'll be fine.

Pictures

For:

- Triumph Bonneville Bobber
- Triumph Bonneville Speedmaster (2018 and newer)



