




NewBonneville “BillyBar” Highway Bars
LONG



- 1) Remove the (2) top bolts from the frame plate.
- 2) Note the angle of the foot peg when it is in the up position. It should be leaning towards the rear of the bike.
- 3) Place bar bracket over the top (2) holes and replace the bolts.
- 4) Torque to 20Nm./16 lb. ft.